
## The Application of Deep Convolutional Networks for the Classification of ECG Signal



Edward Mina
Professor Byron Wallace Ph.D.
Northeastern University College of Engineering
Boston MA

# ECG Heartbeat Classification: A Deep Transferable Representation

Mohammad Kachuee, Shayan Fazeli, Majid Sarrafzadeh University of California, Los Angeles (UCLA) Los Angeles, USA

Work	Approach	Average Accuracy (%)	
This Paper	Deep residual CNN	93.4	
Acharya et al. [23]	Augmentation + CNN	93.5	
Martis et al. [24]	DWT + SVM	93.8	
Li et al. [25]	DWT + random forest	94.6	



- Performs Very Poorly with a more appropriately split dataset!
- 80/20 or 75/25




A. Arrhythmia Classification and learning the representation

We evaluated the arrhythmia classifier of Section III-B on 4079 heartbeats (about 819 from each class) that are not used

#### What is a heart beat?

- Measured Electrocardiogram (ECG)
- P wave = depolarization of the atria
- QRS = depolarization of ventricles
- T = T wave, which indicates Ventricular repolarization



#### Data

- ECG recordings of 48 patients at Beth-Israel Hospital.
- 30 minutes at 360 sample/sec
  - 650k pts per patient

L	_abeled Hea	Sign	al Data			
	sample_num	type	aux	signal		
0	18	+	(N	0	955	
1	111	L	NaN	1	955	
2	343	L	NaN	2	955	
3	571	L	NaN	3	955	
4	807	L	NaN	4	955	




Figure 1: Raw ECG data for patient 231 with labelled peaks with respect to sample number and unnormalized voltage recording.


#### MIT-BIH ARRHYTHMIA DATABASE

This database is described in


Moody GB, Mark RG. The impact of the MIT-BIH Arrhythmia Database. *IEEE Eng in Med and Biol* 20(3):45-50 (May-June 2001). (PMID: 11446209)

Please cite this publication when referencing this material, and also include the standard citation for PhysioNet:

Goldberger AL, Amaral LAN, Glass L, Hausdorff JM, Ivanov PCh, Mark RG, Mietus JE, Moody GB, Peng C-K, Stanley HE. PhysioBank, PhysioToolkit, and PhysioNet: Components of a New Research Resource for Complex Physiologic Signals. *Circulation* 101(23):e215-e220 [Circulation Electronic Pages; <a href="https://circ.ahajournals.org/content/101/23/e215.full@">https://circ.ahajournals.org/content/101/23/e215.full@</a>]; 2000 (June 13).



## Class Imbalance



## Class Simplification and Reduction

```
{'N': 'Normal beat',
 'L': 'Left bundle branch block beat',
                                                                  For class: N (Normal beat)
 'R': 'Right bundle branch block beat',
                                                                    (N) Normal beat
 'A': 'Atrial premature beat',
                                                                   (L) Left bundle branch block beat
                                                                   (R) Right bundle branch block beat
 'a': 'Aberrated atrial premature beat',
                                                                   (e) Atrial escape beat
 'J': 'Nodal (junctional) premature beat',
                                                                   (j) Nodal (junctional) escape beat
 'S': 'Supraventricular premature beat',
                                                                  For class: S (Supraventricular premature beat)
 'V': 'Premature ventricular contraction',
                                                                    (S) Supraventricular premature beat
 'F': 'Fusion of ventricular and normal beat',
                                                                    (A) Atrial premature beat
 '[': 'Start of ventricular flutter/fibrillation',
                                                                    (a) Aberrated atrial premature beat
 '!': 'Ventricular flutter wave',
                                                                    (J) Nodal (junctional) premature beat
 'l': 'End of ventricular flutter/fibrillation',
                                                                  For class: V (Premature ventricular contraction)
 'e': 'Atrial escape beat',
                                                                    (V) Premature ventricular contraction
 'j': 'Nodal (junctional) escape beat',
                                                                    (E) Ventricular escape beat
 'E': 'Ventricular escape beat',
                                                                  For class: F (Fusion of ventricular and normal bea
                                                                    (F) Fusion of ventricular and normal beat
 '/': 'Paced beat',
                                                                  For class: Q (Unclassifiable beat)
 'f': 'Fusion of paced and normal beat',
                                                                    (/) Paced beat
 'x': 'Non-conducted P-wave (blocked APB)',
                                                                   (Q) Unclassifiable beat
 'Q': 'Unclassifiable beat',
                                                                   (f) Fusion of paced and normal beat
 '|': 'Isolated ORS-like artifact'}
```

#### Normalization

PATIENT: 207


**Norm 1:** Creates a mean of 0, and a std of 1


**Norm 2:** Creates a mean of 0, and y range from [-1 1]


**Norm 3:** Creates a y range from [0 1]

Selected Norm = 3


$$z_i = \frac{x_i - min(x)}{max(x) - min(x)}$$










#### **Effect of Normalization**







## Further Signal Processing...



## Heart Beat Isolation Algo

Given Ecg Signal:

Find peaks w/r sample # (Christov)

$$\textit{Beat}_i = \text{signal}\left[p_i - \frac{p_i - p_{i-1}}{2}; p_i + \frac{p_{i+1} - p_i}{2}\right], \textit{where } p = \textit{peak}$$

Zero\_pad w/r max len


print("sample y vals:: [patient#, HR, Condition Class]:",y[0])


sample y vals:: [patient#, HR, Condition Class]: ['100' '75.536676138855' 'N']

print("X shape:", X.shape)
print("y shape:", y.shape)

X shape: (107726, 539) y shape: (107726, 3)

#### Isolated HB Distribution






#### **Heat Beat Classes**

1 hb.show\_sample\_plots(X=X,y=y,classes=classes,classes\_further=hb.classes\_further,plot\_xlim=1,dims=[2,3])


MAX HB TIME: 1.497222222222222




#### Resampling 360Hz → 125Hz ~65% Reduction

```
hb.show sample plots(X=X resamp,y=y,classes=classes,classes further=hb.classes further,
                     plot xlim=.5, dims=[2,3])
```

0.3




0.3 time [s]





#### 1D CNN


- Effective when examining features from shorter (fixed-length) segments of the data
- 75% Training + 5% Validation
- 20% Test
  - Forced to have all classes present




# Classes Still Unbalanced...










#### 80% Improvement With Unbalanced Class Methods

#### ImbalancedDatasetSampler



data augmentation

original dataset


```
1 for hb.labels in dataloader['train']:
           for hb index, label in enumerate (labels):
             print(hb index,hb[hb index].size(),label.cpu().numpy().shape,Counter(label.cpu()
     0 torch.Size([512, 187]) (512,) Counter({0: 106, 4: 105, 2: 104, 1: 102, 3: 95})
      1 torch.Size([512, 187]) (512,) Counter({3: 110, 2: 106, 4: 104, 1: 97, 0: 95})
      2 torch.Size([512, 187]) (512,) Counter({4: 114, 3: 108, 2: 106, 1: 93, 0: 91})
      3 torch.Size([512, 187]) (512,) Counter({4: 118, 2: 102, 3: 98, 1: 97, 0: 97})
      4 torch.Size([512, 187]) (512,) Counter({1: 110, 4: 102, 2: 102, 0: 101, 3: 97})
      5 torch.Size([512, 187]) (512,) Counter({0: 121, 2: 113, 1: 96, 3: 95, 4: 87})
      6 torch.Size([512, 187]) (512,) Counter({0: 123, 2: 114, 4: 95, 3: 93, 1: 87})
      7 torch.Size([512, 187]) (512,) Counter({4: 115, 3: 110, 0: 99, 2: 95, 1: 93})
      8 torch.Size([512, 187]) (512,) Counter({0: 118, 1: 101, 4: 100, 3: 97, 2: 96})
      9 torch.Size([512, 187]) (512,) Counter({4: 114, 1: 109, 3: 100, 2: 98, 0: 91})
      10 torch.Size([512, 187]) (512,) Counter({0: 112, 2: 109, 4: 98, 3: 97, 1: 96})
      11 torch.Size([512, 187]) (512,) Counter({1: 112, 0: 103, 3: 102, 4: 101, 2: 94})
       1 for hb, labels in dataloader['val']:
[160]
           for hb index.label in enumerate(labels):
             print(hb index,hb[hb index].size(),label.cpu().numpy().shape,Counter(label.cpu()
     0 torch.Size([512, 187]) (512,) Counter({0: 455, 4: 28, 2: 25, 1: 4})
     1 torch.Size([512, 187]) (512,) Counter({0: 473, 4: 18, 2: 18, 1: 3})
     2 torch.Size([512, 187]) (512,) Counter({0: 458, 2: 28, 4: 20, 1: 6})
     3 torch.Size([512, 187]) (512,) Counter({0: 459, 4: 24, 2: 24, 1: 5})
     4 torch.Size([512, 187]) (512,) Counter({0: 472, 2: 21, 4: 17, 1: 2})
     5 torch.Size([512, 187]) (512,) Counter({0: 466, 4: 26, 2: 19, 1: 1})
```

#### **General Observations**

- Best filter size 32 x 5 x 1
  - Larger Values let to validation overfitting
- Best number of "blocks" 4 ~ 5
  - Relatively ineffective after 4
  - If <, lower performance
- Number of Epochs ~ 100
- Batch 512 (as per specified in the paper)
  - Poor loss behavior 128 < & < 1024
- Lesser Performance with Drop Out



#### Results





Evaluating....

TEST ACC: 0.9831499791115443

		precision	recall	f1-score	support
	0	1.00	0.99	0.99	17939
	1	0.82	0.90	0.85	477
	2	0.90	0.98	0.94	1365
	3	0.76	0.87	0.81	157
	4	0.99	0.99	0.99	1605
micro	avg	0.98	0.98	0.98	21543
macro	avg	0.89	0.94	0.92	21543
weighted	avg	0.98	0.98	0.98	21543

#### Results Continued...







- Different Possible Combinations of Classes
- Examination RNN's
- Using bpm as a reference
- Isolate beats different or looking at Signal as whole
- Different Processing Methodology
  - Butterworth with different cutoffs
  - Signal smooth techniques
  - Normalizing methods

# Questions?